

RAVE SL-3484 Galaxy LED
DMX Channels

Channel	Function	Value	Description
1	Master	0	Off
		1-255	Dimmer
2	Red/Green/Blue Control	0	Off
		1-255	Dimmer
3	Green/Yellow/Purple Control	0	Off
		1-255	Dimmer
4	Blue/White/Orange Control	0	Off
		1-255	Dimmer
5	Strobe	0-7	Off
		8-255	Strobe
6	Rotation	0-10	Stop
		10-127	Forward
		128-255	Reverse
7	Command	0-6	Manual
		10-219	Automatic
		220-249	Sound (Lights Off)
		250-255	Sound (Lights On)